



**Tuscan
Skill Level 2**

Shopping List: ArmorFaux Base, Yellow
ArmorFaux Glaze, Rust, Matte
ArmorTools Textured Sponge Roller
ArmorTools Tuscan Trowel
ArmorTools Squeegee
3/8" Nap Paint Rollers

Steps:

1. Apply ArmorFaux Base with 3/8" roller.
2. Apply ArmorFaux Base again, using ArmorTools Textured Sponge Roller.
3. Immediately flatten texture with ArmorTools Tuscan Trowel, let dry.
4. Apply ArmorFaux Glaze with 3/8" roller, removing excess glaze with ArmorTools Squeegee. Let dry.

#AF0010