



**Travertine  
Skill Level 1**

**Shopping List:**

ArmorFaux Base, Bellagio Beige, Pre-Tint  
ArmorFaux Glaze, Marble White, Matte  
ArmorTools Textured Sponge Roller  
ArmorTools Knockdown Knife  
ArmorTools Squeegee  
6" SW Microfiber Roller  
Paint Trays

**Steps:**

1. Apply ArmorFaux Base with ArmorTools Textured Sponge Roller.
2. Immediately knockdown texture with ArmorTools Knockdown Knife.
3. When dry, apply ArmorFaux Glaze with microfiber roller over base, then remove excess glaze with ArmorTool Squeegee.

AFTR - BMW