



Striae
Skill Level 1

Shopping List: ArmorFaux Base Coat, Toscano Taupe, Pre-Tint
 ArmorFaux Glaze, Marble White, Matte
 ArmorTools Squeegee
 3/8" Nap Paint Rollers

Steps: 1. Apply ArmorFaux Base with ArmorTools Textured Sponge Roller.
 2. While wet, brush in vertical pattern with ArmorTools Striae Brush.
 3. When dry, apply ArmorFaux Glaze with microfiber roller over base,
 then remove excess glaze with ArmorTools Squeegee.

#AFS - IIMW