



**Travertine
Skill Level 1**

Shopping List:

ArmorFaux Base, Bellagio Beige, Pre-Tint
ArmorFaux Glaze, Marble White, Matte
ArmorTools Textured Sponge Roller
ArmorTools Knockdown Knife
ArmorTools Squeegee
6" SW Microfiber Roller
Paint Trays

Steps:

1. Apply ArmorFaux Base with ArmorTools Textured Sponge Roller.
2. Immediately knockdown texture with ArmorTools Knockdown Knife.
3. When dry, apply ArmorFaux Glaze with microfiber roller over base, then remove excess glaze with ArmorTool Squeegee.

AFTR - BMW