



Venetian Plaster 2 Skill Level 3

Shopping List: ArmorFaux Venetian Plaster Tint Base, Golden Yellow
 ArmorTools Tuscan Trowel
 3/8" Nap Paint Roller
 400-600 Grit Sandpaper

- Steps:
1. Apply ArmorFaux base using 3/8" roller. Let dry.
 2. Apply ArmorFaux Venetian Plaster with ArmorTools Tuscan Trowel, working in 3' square sections. Apply in thin coats to avoid mud cracking; apply as smoothly as possible. Let each coat dry completely (about 2 hours).
 3. Sand with 400-600 grit sandpaper.
 4. Repeat steps 2 and 3 until desired effect is achieved. The more layers, the deeper the marble-like appearance.
 5. After allowing 8 hours drying time, polish with ArmorTools Tuscan Trowel using circular motions.

AFVP-GY