

ULTRA® PLUS System with MILDEW GUARD™

Repair and Mold & Mildew Remediation Sequence

Strip wallcovering	Strip wallcovering and vacuum gross mold & mildew with Hepa filter vacuum. Replace damaged drywall. If wallcovering will not dry strip, score with PIRANHA™ Scoring Tool and remove with PIRANHA Wallpaper & Paste Remover .
Remove residual adhesive:	Remove with PIRANHA Wallpaper & Paste Remover .
Remove mold & mildew:	Treat with solution of Clorox® Ultra Household Bleach according to manufacturer's directions (after residual adhesive has been removed from surface).
Check for moisture:	Conduct a thorough investigation of all areas where moisture may collect and support fungal contamination and correct each situation.
Repair damaged drywall:	Skim coat damaged drywall. Sand. Allow to dry until fully cured to prevent out-gassing.

Decorative Treatment

Prepare test area:	Apply three sheets of wallcovering using specified ULTRA PLUS Adhesive in test area prepared with 2 coats of ULTRA PLUS PRO-988 Primer . Property Owner, Architect or Responsible Party must approve primer coat and wallcovering installation before proceeding with completion of job.
Prime surface: coat)	Apply two pin-hole-free coats of ULTRA PLUS PRO-988 Primer (3 mil wet per coat)
Apply adhesive:	Apply specified ULTRA PLUS Adhesive to back of wallcovering and install.

Product Order Info:

Product	Size	Item No.
ULTRA PLUS Primer PRO-988	5-gallon	18905
	1-gallon	18901
ULTRA PLUS Adhesive Clear Adhesive PRO-888	5-gallon	18805
	1-gallon	18801
ULTRA PLUS Adhesive Clay Adhesive PRO-788	5-gallon	18605
PIRANHA Concentrate Wallpaper & Paste Remover	1-gallon	206009
PIRANHA GEL Wallpaper & Paste Remover	1-gallon	206019
PIRANHA LIQUID Wallpaper & Paste Remover	1-gallon	206007
PIRANHA Scoring Tool	---	202205

ULTRA PLUS Primer and Adhesive contain mildewcides that prevent growth of mold and mildew on the primer film and adhesive only.